



# 1/6 (Replacement sneet)



#### 2/6 (Replacement sheet)



108

### 3/6 (Replacement Sheet)

302 Header 303 Instructions, e.g., for Defined Conditions:

• aircraft a Hitude Supplemental file section Default farameters 307 File Storage Section

FIG. 3

## 4/6 (Replacement Sheet)




FIG. 4

# 5/6 (Replacement Smeet)




FIG. 5

# 6/6 (Replacement sneet)




FIG. 6